



The separator module is required for the correct operation of the 3 electrode system.

1. The **separator module** must be connected to the **separator socket** located on the side wall of the VBE-7 device using the **PM00249 cable**.
2. The **tongs** must be connected to the **separator tongs socket** with the **PM00252 adapter**.

Separator sockets:



1. VBE-7 socket
2. Separator socket
3. Adapter tongs socket
4. Electrovalve tongs socket
5. Electrovalve 3 electrode
6. 3 electrode



ATTENTION!

Connecting the separator module automatically deactivates the main tongs socket;
 The separator module can be connected and disconnected while the **VBE-7** device is turned on.